

Safety Bulletin :	SB-1
Issue date :	Nov. 27, 2014
Language :	EN (Primary language, also in IT, ES , FR)
Product affected:	W420
S/N or other info	From 972580630 to 972580733
Problem / Defect	No correct activation in case of emergency
Severity	Level 3 (1 – aesthetic , 2 – random problem , 3 – requires action)
Description	<p>Following an internal inspection and on the basis of some reports from customers / distributors, it was found that on some equipment mod. W420 there may be a malfunction in the activation.</p> <p>Wamblee invites customers who purchased product according above serial numbers, to effect an operation test as described below:</p> <ol style="list-style-type: none"> <li>1. take the W420 device</li> <li>1. turn the red main activation knob on "ACTIVE" position</li> <li>2. press the manual activation button (black coloured) for at least 1 second and then release it</li> <li>3. verify that the red led of the device stays on and that in 5 seconds the white flashing light begins to flash</li> <li>4. if the conditions described at point 4 take place, your device works properly. Then, you can turn the red knob on OFF position in order to turn the device off</li> <li>5. if the device does not keep the red led on and/or does not flash in 5 seconds, the device does not work properly so it must be sent back to the dealer/distributor or sent back directly to Wamblee for replacement.</li> </ol> <p>We are sorry for the inconvenience and thank you in advance for your cooperation.</p> <p>Note: Owners of these devices registered in our registration website that covered in these serial numbers will be notified directly to the e-mail address entered.</p>
Safety Bulletin deadline	No deadline
Reference	<p>Please check in our website address of distributors :</p> <p><a href="http://www.wamblee.it/distributors/">http://www.wamblee.it/distributors/</a></p> <p>or contact our company</p> <p><a href="http://www.wamblee.it/where-we-are/">http://www.wamblee.it/where-we-are/</a></p>

# Safety Bulletin